

BSX1000 High Capacity Walk Through

High Capacity Walk Through Boot Scrubber Unit

The BSX1000 is a wet, walk through, dual boot scrubber. This unit is designed for facilities where high throughput is critical. The user activates the system by stepping onto the platform. Diluted cleaning solution is sprayed onto rotating brushes and transferred onto the boots from a stainless steel venturi dilution valve and metering tip to provide the desired PPM.

We recommend using Alpet[®] No-Rinse Quat Sanitizer with the BSX1000 to aid in the cleaning of footwear prior to sanitizing (sanitization can only occur on pre-cleaned footwear). The BSX1000 uses two rotating disk brushes and two long horizontal sole brushes, while the BSX1000-V uses 3 vertical rotating brushes and two long horizontal sole brushes. Both of these configurations provide multiple points of contact between brush and boot. These units are designed for larger spaces and higher traffic applications.

Features

- Solid member stainless steel frame construction
- Hinged stainless steel access grate, two removable stainless steel steps, removable combination brush assembly with one brush for each sole and four disk brushes for sides of feet, and two 33" long removable sole brushes
- Stainless steel electrical enclosure with variable speed drive, timer and e-stop
- Proximity sensor and spring loaded grate for unit activation
- Three stainless steel washdown rated 1/2hp motors and three worm gear reducers
- Self draining tub with four adjustable dairy approved feet
- Solenoid activated brush spray system with Venturi injector for sanitizer with flow rated at 2.5 Gpm

Connection Requirements

Throughput

Distributed By:

• 3 users at a time

15-25 users per minute

- 220V ac, single phase, 15 amp electrical connection required
- 3/8" Nptf cold water connection, 50psi recommended
- 1.5" Tri-clamp drain connection

Where to Use

- High number of employees
- Plants with plenty of open space
- Areas with access to water lines
- Areas with accessible floor drains

Dimensions	Height 54" x Width 45" x Length 96"	Weight	800 LB

BSX1000-DAFBoot Scrubber w/ Dairy Approved FeetBSX1000V-DAFBoot Scrubber w/ Vertical Brushes and Dairy Approved FeetBSX1000V-DAF-6Boot Scrubber w/ 6" Vertical Brushes and Dairy Approved Feet



Complete, Confident, Compliant. www.bestsanitizers.com | 888.225.3267

Use Alpet[®] No-Rinse Quat Sanitizer with the BSX1000 to aid in the

cleaning of footwear

prior to sanitization.

