

Elite EES-L-RC ISO 7



View online: <https://www.biofit.com/product/elite-series-technical-chair-steel-base-low-seat-height-iso-7-clean-room/476>



This desktop height Elite Series chair features an ISO 7 clean room performance package with Grade 2 black vinyl upholstery. Components include a mid-sized adjustable seat, ergonomic functionality, a back engineered for all-day comfort, and a steel base with an affixed foot ring.

Manuf Code: EES-L-RC-T-XF-XA-ISO7-06-P28540

Recommended For: ISO 7 clean rooms

Use In: ISO 7 clean rooms, technical settings



Available via standard shipping



Key Features

Height Compatibility: Desk (L)

Seat Size: Medium

Back Size: Medium

Base: Steel / Tubular Steel

Finish Color: Black Powdercoat

Seat-Height Adjustable Range (in.): 18-22

ISO Clean Room Standard: ISO 7

Upholstery Type & Color: Grade 2 Black Vinyl
P28540

Recommended User Height: for work surfaces 30" to 34"

Seat Description: Ergonomic upholstered seat with four-way contouring and internal seat board bumperguard; measures 18.5" wide x 17" deep x 3" thick.

Back Description: Upholstered backrest with lumbar support and plastic protective panel; measures 15.5" wide x 14.5" high.

Control Description: Control allows function of the seat height activation and backrest adjustments by means of easily engaged levers which can be activated from the seated position. Seat tilt is fixed at 3.5° rearward while the backrest adjusts 8° forward and 13° rearward.

Base Description: Small, five-legged base with caster-to-caster diameter of 23.0" and maximum width of 22.8". Welded 1" x 14-gauge steel tubular legs withstand test loads of 2X BIFMA strength requirements. Features standard 50mm, steel-reinforced, tapered hub, and a 21" affixed steel tubular footring welded to top of legs at 8" above floor height. A reinforced nylon insert at the end of each leg accepts a caster or glide stem. The welds at the hub are concealed by a two-piece, polypropylene cover.

Footring Description: Includes 21" affixed steel tubular footring welded to top of legs.

Caster Glide Description: Two inches in height, with dual soft-wheels. Casters resist movement when the seat is unoccupied. Plastic collar around caster stem to match base. Standard casters have grey tread.

Specifications

Weight: 43.0 lbs

Dimensions: 23 x 23 x 37

Seat Width (in.): 18.5

Seat Depth (in.): 17

Seat Cushion Thickness (in.): 3

Back Width (in.): 15.5

Back Height (in.): 14.5

Footring Diameter (in.): 21

Fire Retardancy Standards: CAL117

Weight Capacity: 300

Additional Info

Elite Series seating model outfitted with critical use performance packages are engineered for use in technical environments in a variety of industries.

This chair features an ISO 7 clean room performance package and is designed for use in 30" to 34" desktop height. Features include easy pneumatic seat height adjustments from 18" to 22" , an ergonomic seat with four-way contouring and internal seat board bumperguard measuring 18.5" wide x 17" deep x 3" thick, an upholstered backrest with lumbar support and plastic protective panel; measures 15.5" wide x 14.5" high. The seat and back are covered with Grade 2 blue vinyl upholstery. The chair rests on a rugged 23" diameter tubular steel base with a 21" diameter affixed footing with dual-wheel, non-marring polyurethane casters that resist movement when the chair is unoccupied. Metal parts have black powder-coat finish finish.

Complies with product safety and performance standards guidelines as established by the American National Standards Institute (ANSI) and Business Institutional Furniture Manufacturers Association (BIFMA).

Meets CAL 117 fire retardant standards. LEED compliant.

Backed by a 13-year warranty with lifetime warranty on pneumatics.

Your BioFit Sales Representative

Mark Romey

800-365-6465 **office**
info@westrepenterprises.com

Contact BioFit

BioFit Customer Service

Customer Service: (800) 597-0246
Online: <https://www.biofit.com/contact>

Office Address:

15500 BioFit Way
Bowling Green, OH 43402

Mailing Address:

PO Box 109
Waterville, OH 43566